


Citroën C5 II HB & Break 10/2004 - 09/2008
Citroën C5 III Sedan & Tourer 03/2008 - 09/2008

Part No: PE-059-D1U

Electric wiring kit for towbars / 7-pin / 12N / 12 Volt / ISO 1724 Fitting instructions



IMPORTANT!

This electric kit has to be installed by a professional workshop or a suitable qualified person.

The installation instructions must have been read and fully understood before the start of any installation. Please contact your wiring kit provider or the hotline shown in the footer should you need assistance!

Make sure the vehicle is approved/homologated by the manufacturer to tow a trailer!

Also please check that there is a definite compatibility between this vehicle and the electric kit!

Following the installation of the electric kit, the fitting instructions should be kept together with the vehicle service document and vehicle handbook. The fitting instructions contain important information relating to the use and function of the towing kit as well as for any diagnostic or activation process, that might have to be repeated in the future (e.g. after the performance of a vehicle software update).

All warranty claims will be forfeited if the electric kit or components contained therein are used incorrectly or modified. If a towing socket adaptor has been used to connect to the trailer or bike rack, this must be removed from the trailer socket once the trailer or bike rack has been disconnected.

If the trailer or bike rack is not equipped with a rear fog lamp, depending on the towing vehicle type, the correct function of the towing kit cannot be guaranteed. In such cases, a rear fog lamp should be retro fitted.

This towing electric kit will not be covered under warranty if any technical or electrical modifications or software updates have been performed by the vehicle manufacturer after the initial commissioning of the kit. That applies especially to modifications or updates which may cause malfunctions in the trailer socket or any other part of the trailer electrical equipment!

Depending on the type of trailer module used in this electric kit, diagnostic interrogation with the vehicle's electrical system may be limited or will not function. The error memory inside the trailer module may not be able to be accessed by vehicle manufacturers diagnostic system.

Error logs relating to the trailer electrical equipment, that may be generated in the vehicle manufacturers diagnostic system as a result of a test procedure, may be due to the incorrect installation of the towing electric kit or the false activation of the trailer module.

We always recommend whenever possible, the following troubleshooting process:

→ **An analysis of the vehicle's error memory and possibly clearing of all faults before the start of the installation!**

→ **Try disconnecting the trailer module from the towing harness and re-start the fault clearing process!**

→ **If in doubt, limit the time for troubleshooting to a max of 0,5 hours and call our Technical Support Team!**

Please follow our instructions carefully and always test the towing electrics using a true lighting board or a specifically designed bulb tester. If an LED tester is used, ensure it is equipped with correct load resistors or malfunctions will occur!

This instruction is subject to changes and we reserve the right to make changes to design, colour etc.

All of the data and illustrations may not be an exact representation but the text contained in this instruction must be observed!



2x

4x



L2

G

UN-243-YZ

Optional reverse lamp pre-wire extension included

Pag. 20



U1

Optional SP-161-ZZ

Fog off extension harness



Pag. 14-15


Optional UN-209-ZZ

U4




U5

Pag. 13



M




3x





3x



1x




1x




20 Amp.

2x




30 Amp.

1x




1x



1x




1x



1x









U3



8-13

14-22





SYMBOL EXPLANATION

	Left (58-L) respectively Right (58-R) tail light
54	Stop light (54) / high mounted, third stop light (54)
	Turn signal indicator left
	Turn signal indicator right
	Rear fog light(s)
	Reversing light(s)
	Permanent power supply / 13pin socket, chamber 9
	Charging wire for trailer battery / 13pin socket, chamber 10
	Trailer / trailer recognition
B+ / 30	Permanent current power supply
	Ground or Earth (31)
	Ground connection battery terminal lug
	Positive connection battery terminal lug


	Cigarette lighter / accessory socket
	Loudspeaker / buzzer
	Park Distance Control
	Switch / source of function
	Connect together
	Disconnect
	Look at / See further information
	Look carefully at selected area
	Present / Occupied / OK
	Not present / Not occupied / Not OK
	Acoustic indication
	Attention / important advice
	Fuse / fuse capacity 20 Ampere

TOOLS



ATTENTION!

The vehicle's cooling capacity may have to be increased when retrofitting a trailer coupling!
You must observe the manufacturer's instructions!!



Note: It may be necessary to check if this vehicle has a stored radio code before disconnecting the battery!



ATTENTION!

In order to avoid mal-functions and damage to the vehicle's electrical system the earth terminal **must be disconnected** from the vehicle's battery **before starting work!**


Both the trailer module and the vehicle's control unit for the electrical system can be damaged during work on the data bus connections if the battery is not disconnected!

1 Please pay attention to the manufacturer's instructions when disconnecting and reconnecting the vehicle's battery!

INFO




Org / DAM
10174 → 11922



2

C5 II Break


C5 III Tourer



3


C5 II Break

C5 III Tourer




4

C5 III Sedan




5

C5 II HB



6

C5 II HB





7




C5 II Break


C5 III Sedan

C5 III Tourer



C5 II HB






11

SOCKET CONNECTION





Page 21


12




13




1



2




3



4


14

C5 II Break



15


C5 II HB




16

C5 III Sedan

C5 III Tourer



17




C5 II Break

C5 II HB




C5 III Sedan

C5 III Tourer




OPTION A


OPTION B




OPTION A




1



2




3




L2

4

OPTION B








L2




C5 II Break

C5 II HB




1

+30 \Rightarrow \varnothing 5 mm² **White/Grey**
code: BH38 BH40



L1



2




3

	54	code: 210	\Rightarrow	\varnothing 0.5 mm ²	Yellow	\Rightarrow \Leftarrow	L1 Red/Blue
	Can H	code: 9017	\Rightarrow	\varnothing 0.35 mm ²	Red/Grey	\Rightarrow \Leftarrow	L1 Red/White
	Can L	code: 9018	\Rightarrow	\varnothing 0.35 mm ²	Brown/Yellow	\Rightarrow \Leftarrow	L1 Brown/Yellow



19



Option 1






Option 2




20

C5 II Break

C5 II HB




1





4x

L1 L2


2



i





3





L1

XX/XX


Pos. X

L1	Red/Blue	→	←	Pos. 6	54 STOP
L1	Red/White	→	←	Pos. 2	Can H 
L1	Brown/Yellow	→	←	Pos. 1	Can L 

4



5



L2

Red

XX

+30 



21

OPTION

C5 II Break

C5 II HB

V6 HDi
DT 17




U4



UN-209-ZZ

Consult your supplier.


U4



L2

1


U5



2

22


20 Amp.



L3

23


-




24

LIGHT MATE


Tester lamp 




Tester L.E.D. 



OFF




TEST 



ON




TEST     




25

Only for
O.E.M. PDC




C2



26

OPTION SP-161-ZZ





Optional SP-161-ZZ



Consult your supplier.

27


OPTION SP-161-ZZ



28





SP-161-ZZ   PE-059-D1U

OPTION SP-161-ZZ INFO







289
290

C5 II Break




201A
201B

C5 II HB




C5 III Sedan

C5 III Tourer



Citroën C5 III # 2052
Tourer III # 2052k

Citroën C5 III # 2053
Tourer III # 2053k



Optional






Consult your supplier.





Trailer Simulator for 7- and 13-pin Sockets

30




31





32

Optional


Adapter socket



33




34







35



L		54	
R	➔	54G	⚡
58L	⚡	Ground/31	⏚
58R	⚡		







R	1	-	-	-
	2	Blue	54 G 0≠ trailer	in
		Blue	54 G 0≠ trailer	out
	3	-	-	-
	4	-	-	-
	5	Grey	54G R 0≠	out
	6	Red	54G	in
	7	-	-	-
	8	White	Ground ⊥	-
	9			

UN-243-YZ Reverse lamp pre-wire extension


! MAX = 21W




A




1




2




3



4





5





B

! MAX = 21W



SOCKET CONNECTION



SOCKET CONNECTION

DIN/ISO 1724							
Pmax	21W	21W		21W	42W	3x21W	42W
Colour	Yellow	Blue	White	Green	Brown	Red	Black