








Ford Ranger 2012 >>

Partnr.: FR-053-B1U

- Fitting instructions electric wiring kit tow bar with 12-N socket up to DIN/ISO Norm 1724.
- We would expressly point out that assembly not carried out properly by a competent installer will result in cancellation of any right to damage compensation, in particular those arising by virtue of the product liability act.
- Contents of these kits and their fitting manuals are subject to alteration without notice, please ensure that these instructions are read and fully understood before commencing installation.
- Do not overload circuits; the maximum loads per connection are detailed in this manual.
- Attention! Before Installation, please read this manual carefully and inform your customer to consult the vehicle owners manual to check for any vehicle modifications required before towing.
- In the event of functional problems, troubleshooting must be limited to about 0.5 hours, contact the technical support:
ukts@ecs-electronics.com / 07440 202 052.







Part list





UN-243-YZ
 Optional reverse lamp
 pre-wire extension included

Pag. 10




20 Amp.


ROUTING





1




2






3




4




5




6



7



1





2

INFO



SOCKET CONNECTION 

Pag. 9



8




9




10




2





3





4




11




12




Option 1




2pole Grey




5pole Green




Option 2



2pole Grey




4pole Black



13


Option 1



2pole Grey

L1


1



5pole Green


L2

2



14


Option 2



2pole Grey



L1

1



4pole Black

L2




2










Brown	→	Grey/Orange
Green	→	Purple/Orange
Blue/Red	→	Black/Blue


3




15



16



1



2

17




18

TEST ALL THE CIRCUITS WITH A TEST DEVICE WITH THE CORRECT POWER LOAD FOR EACH FUNCTION. A TEST DEVICE WITH LED'S CANNOT BE USED FOR THIS PURPOSE.

INFO

REINSTALL TRIM.

19




INFO

SOCKET CONNECTION


DIN/ISO 1724								
	1/L	2	3/31	4/R	5/58-R	6/54	7/58-L	8
Pmax	21W	21W		21W	42W	3x21W	42W	
Colour	Yellow	Blue	White	Green	Brown	Red	Black	Grey

UN-243-YZ Reverse lamp pre-wire extension


⚠ MAX = 21W




A




1




2




3



4



5



B

⚠ MAX = 21W

